


ROZPADOVÁ SCHÉMA NÁHRADNÝCH DIELOV



Č.	Názov dielu	Počet	Č.	Názov dielu	Počet
1	E-parts components	1	5	Middle frame assy	1
1.1	Indoor terminal	1	6	Air outlet panel components	1
1.2	Main control box	1	7	Louver assy	1
1.3	Groove clamp	1	8	Step motor	1
1.4	Temperature sensor for indoor unit	1	9	Fixing tube panel	1
1.5	Indoor E-parts	1	10	Main air-out assy	1
2	Indoor motor	1	11	Cross flow fan	1
3	Motor cover assy	1	12	Base assy	1
4	Evaporator components	1	5	Middle frame assy	1
4.1	Evaporator welding assy	1	6	Air outlet panel components	1
4.2	Evaporator damping rubber strip	1	7	Louver assy	1
4.3	Insulation tube	1			