


ROZPADOVÁ SCHÉMA NÁHRADNÝCH DÍLOV



Č.	Názov dielu	Počet
1	Electrical lifted the lid	1
2	Electronic components	1
2.1	Electric control board seats	1
2.2	Electrical box welded components	1
2.3	The temperature sensor group	1
2.4	Stepper motor line	2
2.5	Indoor motor winding connection	1
2.6	Terminal station	1
2.7	Quad lamp plate connection	1
2.8	Indoor plate component	1
2.9	Insert the fan capacitance	1
3	Guide solar or lunar halo	1
4	Bubble water pans components	1
5	Pump parts	1
5.1	Drainage to take over the component	1
5.2	The water pump	1
5.3	Water pump gasket 2	1
5.4	Water pump gasket 1	1
5.5	Water pump about seat	1
5.6	Water pump brace	1
6	The evaporator components	1
6.1	Welded components evaporator	1
6.2	Back to the trachea components	1

Č.	Názov dielu	Počet
6.3	Evaporator bypass capillary components	1
7	End plate fixed plate component	1
8	Centrifugal wind leaf	1
9	The motor	1
10	The motor bracket	1
11	Chassis bubble component	1
12	Lug 2	3
13	After the coaming components	1
14	Chassis parts	1
14.1	Chassis external thermal insulation cotton	1
14.2	Chassis welded components	1
14.3	Fan wire fixed plate	1
15	Lug 1	1
16	Refrigerant tube support plate component	1
17	Expansion valve connecting pipe component	1
18	Electronic expansion valve box parts	1
18.1	Stick cotton component	1
18.2	Cover plate stick cotton parts	1
18.3	Electronic expansion valve welding components	1
19	Dash panel stick cotton component	1
20	Water level switch	1
21	The evaporator pressure	1