


## ROZPADOVÁ SCHÉMA NÁHRADNÝCH DIELOV



| Č. | Názov dielu                             | Počet | Č. | Názov dielu                           | Počet |
|----|-----------------------------------------|-------|----|---------------------------------------|-------|
| 1  | Chassis assembly                        | 1     | 15 | Mesh enclosure                        | 2     |
| 2  | The right side of the valve plate       | 1     | 16 | Uniaxial outdoor motor                | 2     |
| 3  | Valve seat plate                        | 1     | 17 | Electronic control unit               | 1     |
| 4  | Posterior valve plate                   | 1     | 18 | Condenser                             | 1     |
| 5  | The right side plate                    | 1     | 19 | The high pressure stop valve assembly | 1     |
| 6  | The back plate                          | 1     | 20 | The exhaust pipe A                    | 1     |
| 7  | The baffle plate welding assembly       | 1     | 21 | Exhaust pipe assembly                 | 1     |
| 8  | Motor frame connecting plate            | 1     | 22 | Return pipe assembly                  | 1     |
| 9  | The top cover with cotton component     | 1     | 23 | Electronic expansion valve assembly   | 1     |
| 10 | Front panel                             | 1     | 24 | The four valve assembly               | 1     |
| 11 | Assembly welding motor bracket          | 1     | 25 | Compressor                            | 1     |
| 12 | The motor fixing plate welding assembly | 2     | 26 | Gas-liquid separator                  | 1     |
| 13 | Axial flow fan                          | 2     | 27 | Receiver                              | 1     |
| 14 | Frame                                   | 1     | /  | /                                     | /     |